



2012-2015 Honda Civic Honda Key Battery Replacement

The key remote is important for unlocking and locking the car, opening the trunk and activating panic mode. Over time, the battery in the key will die.

Written By: monica



INTRODUCTION

Use this guide to replace a 2012-2016 Honda Civic key remote battery.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Spudger](#) (1)



PARTS:

- [Panasonic CR1620 battery](#) (1)
-

Step 1 — Honda Key Battery



- Lay the key down so that the Honda symbol is facing upward.
- Use a Phillips #0 screwdriver to remove one screw.

Step 2



- Insert the flat end of the Spudger into the side of the key remote.
- Pry the key remote apart to remove the cover.

Step 3



- Remove the existing battery.
- Insert a new CR1616 battery with the '+' sign facing upward.

Step 4



- Place the two halves of the remote cover back together.
- Press the unlock or lock buttons to make sure the remote is working.
- Place the screw into the hole and tighten with a Phillips #0 screwdriver.

To reassemble your device, follow these instructions in reverse order.